

Instrument Approach Chart

Juan Santamaría International Airport

RNP E RWY 25 (AR)

RNP AR

RF Required

IAF OKOPU

WPT	Path Terminator	Fly-over	LAT	LONG	T TR	VAR (W)	MAG TR	Turn Direction	ALT (ft)	DIST (NM)	IAS (kt)	VPA/TCH	NAV Specification RNP AR APCH
OKOPU	IF	—	09°43'42.8"N	083°50'50.0"W	—	2.0	—	—	@12000	—	-250	—	0.3
OC804	TF	—	09°48'55.2"N	083°56'02.4"W	315.2	2.0	317	—	+10000	7.3	-250	—	0.3
OC803	TF	—	09°54'7.4"N	084°01'15.0"W	315.2	2.0	317	—	+8000	7.3	-210	—	0.3
OC801	TF	—	09°56'23.9"N	084°04'58.7"W	301.6	2.0	304	—	@6300	4.3	-185	—	0.3
OC806	RF Centre: OC889 r=2.26 NM	—	09°58'33.2"N	084°06'03.6"W	—	2.0	—	R	+5500	2.5	—	—	0.3
OC805	RF Centre: OC888 r=2.26 NM	—	10°00'53.8"N	084°09'09.2"W	—	—	—	L	—	4.6	—	—	0.3/0.1
DTHR 25	TF	Y	09°59'49.6"N	084°12'01.0"W	249.3	2.0	251	—	—	3.0	—	-3.0/ 50 ft	0.3/0.1
OC807	TF	Y	09°52'36.6"N	084°31'17.0"W	249.3	2.0	251	—	+7000	20.3	—	—	1.0
OC807	HM	Y	09°52'36.6"N	084°31'17.0"W	249.3	2.0	251	R	+7000	—	-230	—	1.0

RF Arc Centre Identifier	Coordinates
OC888	09°58'46.2"N 084°08'20.6"W
OC889	09°58'20.1"N 084°03'46.5"W